Prager & Co. KG übernimmt keine Haftung für eine unsachgemäße Verwendung dieser Produkte. Prager & Co. KG kann nicht für Schäden an Personen, Gegenständen oder Geräten verantwortlich gemacht werden, die sich bei der Nutzung dieser Werkzeuge ergeben.

NR. 9295 - TASCHEN-GASBRENNER

BEDIENUNGS- UND SICHERHEITSHINWEISE

Allgemeine Hinweise

- Lesen Sie vor Gebrauch die Anleitung sorgfältig.
- Bewahren Sie diese Anleitung gut auf. Händigen Sie alle Unterlagen bei Weitergabe des Produktes an Dritte ebenfalls mit aus.
- Der Taschen-Gasbrenner ist ausschließlich zum Erhitzen, Löten und Flämmen bestimmt. Andere Verwendungen oder Veränderungen am Produkt gelten als nicht bestimmungsgemäß und können zu Verletzungen oder Beschädigungen führen.
- Für Schäden, die aus unsachgemäßer Verwendung entstehen, übernimmt der Hersteller keine Haftung.

Sicherheitshinweise

WARNUNG

Lebens- und Unfallgefahr für Kleinkinder und Kinder! Lassen Sie Kinder niemals unbeaufsichtigt mit Verpackungsmaterial und Produkt. Es besteht Erstickungsgefahr durch Verpackungsmaterial. Kleinteile können verschluckt werden! Kinder unterschätzen häufig die Gefahren!

- Seien Sie vorsichtig, wenn Sie den Taschen Gasbrenner in der Nähe von Feuerquellen, Heizkörpern oder brennbaren Materialien verwenden – ausströmendes Gas kann sich entzünden!
- Die Brennerdüse nicht während der Benutzung oder unmittelbar nach dem Gebrauch berühren – Verbrennungsgefahr!
- Bei längerer Nutzung das Gerät zwischendurch abkühlen lassen!
- Vor der Lagerung unbedingt darauf achten, dass die Flamme in der Brennerdüse erloschen und die Brennerdüse ausreichend abgekühlt ist – Brandgefahr!
- Eine Demontage oder Reparatur ist nur durch geschultes Fachpersonal gestattet. Das Gerät bei Beschädigung nicht weiter benutzen!

ACHTUNG

Nur zur Verwendung mit Universal Feuerzeuggas (Butan).

Erstbenutzung

- Das Füllventil zum Füllen des Taschengasbrenners befindet sich im unteren Teil. Zur Befüllung drehen Sie das Gerät um und drücken die Feuerzeuggas-Kartusche mit dem geeigneten Fülladapter gegen das Gasfüllventil. (Abb. 1)
- **HINWEIS**: Warten Sie nach dem Befüllen einige Minuten, bis das Gas im Inneren des Gerätes einen gleichmäßigen Druck aufgebaut hat und das überschüssige Gas verzogen ist!

Anwendung

- Drehen Sie den Zündknopf der Piezo-Zündung von Position “close“ in Position “open“ (Abb. 2)
- Schieben Sie den Gasmengenregulierer ca. 1/3 nach rechts in Richtung “+“ und drücken den Auslöser zum Zünden der Flamme. Die Flammengröße können Sie über den Gasmengenregulierer steuern. (Abb. 3)
- Zum Fixieren der Gaszufuhr drehen Sie den Zündknopf von Position “open“ in Position “close“.
- **HINWEIS**: Zur Lagerung den Zündknopf IMMER auf Position “close“ drehen und den Gasmengenregulierer komplett nach links in Richtung “-“ schieben! (Abb. 3)







EU KONFORMITÄTSERKLÄRUNG

Wir erklären in alleiniger Verantwortung, dass die Bauart des Produktes folgenden einschlägigen Bestimmungen entspricht:

Artikelbeschreibung:	Taschen-Gasbrenner
Artikelnummer:	9295
Zutreffende Richtlinien:	EU 2016/426
Angewandte Normen:	EN 521:2019+AC:2019
Zertifikats-Nr.:	G-019-21 rev.2
Test Report Nr.:	702959/3

Remscheid, 27.03.2026 - Richard Prager, Prokurist
Prager & Co. KG I Walter-Freitag-Str. 9 I 42899 Remscheid I Germany

Prager & Co. KG does not accept any liability for incorrect use of any of these products. Prager & Co. KG cannot be held responsible for any damage to personnel, property or equipment when using these tools.

NO. 9295 - POCKET GAS TORCH

DIRECTIONS FOR USE AND SAFETY INSTRUCTIONS

General notes

- Read the instructions carefully before use.
- Keep these instructions for future reference and include these instructions if you pass on the product to third parties.
- The pocket gas torch is intended solely for heating, soldering and flame-cutting. Any other use or modification of the product is considered improper and may result in injury or damage.
- The manufacturer accepts no liability for damage resulting from improper use.

Safety notes

WARNING

Life and accident risk for toddlers and kids! To avoid danger of suffocation, keep packaing materials away from babies and children. Risk of suffocation due to packing material. Small parts can be swallowed! Children often underestimate the dangers

- Take care when using the portable gas burner near sources of fire, radiators or flammable materials – escaping gas may ignite!
- Do not touch the burner nozzle during use or immediately after use – risk of burns!
- If using the device for a prolonged period, allow it to cool down occasionally!
- Before storing, ensure that the flame in the burner nozzle has gone out and that the burner nozzle has cooled down sufficiently – risk of fire!
- Disassembly or repair is permitted only by trained specialist personnel. Do not continue to use the device if it is damaged!

ATTENTION

For use with standard lighter gas (butane) only.

First use

- The filling valve for refilling the pocket gas torch is located at the bottom. To refill, turn the device upside down and press the lighter gas cartridge against the gas filling valve using the appropriate filling adapter. (Fig. 1)
- **NOTE**: After filling, wait a few minutes until the pressure inside the appliance has stabilised and any excess gas has been released!

Operation

- Turn the ignition knob on the piezo ignition from the “close” position to the “open” position (Fig. 2)
- Slide the gas flow regulator approximately 1/3 of the way to the right towards “+” and press the trigger to ignite the flame. You can control the size of the flame using the gas flow regulator. (Fig. 3)
- To stop the gas flow, turn the ignition knob from the “open” position to the “close” position.
- **NOTE**: When storing the unit, ALWAYS turn the ignition switch to the “close” position and slide the throttle control fully to the left towards the “-” mark! (Fig. 3)







EU DECLARATION OF CONFORMITY

We hereby declare under our sole responsibility that the pocket gas torch specified here conforms to the relevant directives:

Article designation:	Pocket Gas Torch
Article number:	9295
Applicable directive:	EU 2016/426
Applied standards:	EN 521:2019+AC:2019
Certificate No.:	G-019-21 rev.2
Test Report No.:	702959/3

Remscheid, 27.03.2026 - Richard Prager, Prokurist
Prager & Co. KG I Walter-Freitag-Str. 9 I 42899 Remscheid I Germany